This list is based on the latest firmware of each iPod and iPhone. Please update to the firmware of latest version.
If you update your iPod touch or iPhone, please restart it.
This list is applied to iPod and iPhone which have Dock Connecter. Not applied to iPod shuffle.

		iPod 3rd generation 10GB/15GB/20GB	iPod 3rd generation 30GB/40GB	iPod mini	iPod 4th generation 20GB	iPod 4th generation 40GB	iPod 4th generation(color display) 20GB/30GB	iPod 4th generation (color display) 40GB/60GB	iPod nano 1st generation	iPod 5th generation(video) 30GB	iPod 5th generation(video) 60GB/80GB	iPod nano 2nd generation (aluminum)	iPod classic (2007)	iPod nano 3rd generation(video)	iPod touch 1st generation	iPhone	iPod nano 4th generation(video)	iPod classic (2008)	iPod classic (2009)	iPod touch 2nd generation*20	iPhone 3G	iPhone 3GS	iPod nano 5th generation (video camera) 8GB/16GB	iPod touch 3rd generation*20	iPad, iPad 3G iPad(Wi-Fi), iPad(Wi-Fi + 3G)		
KS-PD100	Play/ Search Mode	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓*1	✓	✓	-	**1	✓	✓	✓	-	**1	**1	✓	-	**2	Play/ Search Mode	KS-PD100
	Charge	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**1	*8	✓	*8	*8	**1	**1	*8	*8	**2	Charge	
KD-PDR30 KD-PDR31 KD-PDR35 KD-APD38 KD-PDR51 KD-PDR55 KD-APD58	Play/ Search Mode	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	**1	✓	✓	✓	-	**1	**1	✓	-	**2	Play/ Search Mode	KD-PDR30 KD-PDR31 KD-PDR35 KD-APD38 KD-PDR51 KD-PDR55 KD-APD58
	Charge	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**1	*8	✓	*8	*8	**1	**1	*8	*8	**2	Charge	
KD-PDR40 KD-APD49 KD-PDR45 KD-PDR49 KD-PDR41*4 KD-G647*4	Play/ Search Mode	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**1	✓	✓	✓	✓	**1	**1	✓*21	✓	**2	Play/ Search Mode	KD-PDR40 KD-APD49 KD-PDR45 KD-PDR49 KD-PDR41*4 KD-G647*4
	Head/ iPod Mode	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**1	✓	✓	✓	✓	**1	**1	✓	✓	**2	Head/ iPod Mode	
	Charge	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**1	*8	✓	*8	*8	**1	**1	*8	*8	**2	Charge	
KD-PDR80 KD-APD89 KD-PDR89 KD-PDR81 KD-G844 KD-G845 KD-G847 KD-BT22 KD-ABT22	Play/ Search Mode	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓	✓	✓	✓	✓	✓	✓	**1	✓	✓	✓	✓	**1	**1	✓*21	✓	**2	Play/ Search Mode	KD-PDR80 KD-APD89 KD-PDR89 KD-PDR81 KD-G844 KD-G845 KD-G847 KD-BT22 KD-ABT22
	Charge	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**1	✓	✓	✓	✓	**1	**1	✓	✓	**2	Charge	
KD-DV7400*6 KD-ADV7490*6 KD-DV7401/2*6 KD-DV7404*6 KD-DV7405/6*6 KD-DV7407/8*6	Play/ Search Mode	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓	✓	✓	✓	✓	✓	✓	**1	✓	✓	✓	✓	**1	**1	✓*21	✓	**2	Play/ Search Mode	KD-DV7400*6 KD-ADV7490*6 KD-DV7401/2*6 KD-DV7404*6 KD-DV7405/6*6 KD-DV7407/8*6
	Artwork on Video Out	-	-	-	-	-	-	-	-	-	-	-	-	-	-	**1	-	-	-	-	**1	**1	-	-	**2	Artwork on Video Out	
	Video Browsing on Video Monitor	-	-	-	-	-	-	-	-	✓*2*5	✓*2*5	-	✓*2*5	✓*2*5	✓*2*5	**1	✓*2*5	✓*2*5	✓*2*5	✓*2*5	**1	**1	✓*2*5	✓*2*5	**2	Video Browsing on Video Monitor	
	Charge	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**1	✓	✓	✓	✓	**1	**1	✓	✓	**2	Charge	
KD-AVX22*6 KD-AVX44*6 KD-ADV49*6 KW-AVX810*6 KW-AVX814*6 KW-AVX815*6 KW-AVX816*6 KW-AVX818*6 KW-NX7000*6	Play/ Search Mode	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓	✓	✓	✓	✓	✓	✓*7	**1	✓	✓	✓	✓*7	**1	**1	✓*21	✓*7	**2	Play/ Search Mode	KD-AVX22*6 KD-AVX44*6 KD-ADV49*6 KW-AVX810*6 KW-AVX814*6 KW-AVX815*6 KW-AVX816*6 KW-AVX818*6 KW-NX7000*6
	Artwork on Video Out and Built-in Monitor	-	-	-	-	-	-	-	✓*15	✓*15	✓*15	✓*15	✓*15	✓*15	✓*7*15	**1	✓*15	✓*15	✓*15	✓*7*15	**1	**1	✓*15	✓*7*15	**2	Artwork on Video Out and Built-in Monitor	
	Video Browsing on Video Monitor	-	-	-	-	-	-	-	-	✓*3*5*17	✓*3*5*17	-	✓*3*5*17	✓*3*5*17	✓*3*5*17	**1	✓*3*5*17	✓*3*5*17	✓*3*5*17	✓*3*5*17	**1	**1	✓*3*5*17	✓*3*5*17	**2	Video Browsing on Video Monitor	
	Charge	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**1	✓	✓	✓	✓	**1	**1	✓	✓	**2	Charge	
KD-AV7100	Play/ Search Mode	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**1	✓	✓	✓	✓	**1	**1	✓	✓	**2	Play/ Search Mode	KD-AV7100
	Video Monitor for iPod 5G	-	-	-	-	-	-	-	-	✓	✓	-	-	-	-	**1	-	-	-	-	**1	**1	-	-	**2	Video Monitor for iPod 5G	
	Charge	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**1	*8	✓	✓	*8	**1	**1	*8	*8	**2	Charge	
KD-R600 KD-R601 KD-R604 KD-R605 KD-A605 KD-R606 KD-R701 KD-R705 KD-R707 KD-R800 KD-R801 KD-R805 KD-A805 KD-R807 KD-R900 KD-R901	Play/ Search Mode	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓*21	✓	**2	Play/ Search Mode	KD-R600 KD-R601 KD-R604 KD-R605 KD-A605 KD-R606 KD-R701 KD-R705 KD-R707 KD-R800 KD-R801 KD-R805 KD-A805 KD-R807 KD-R900 KD-R901
	Head/iPod Mode	-	-	-	-	-	-	-	*13	*13	*13	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Head/iPod Mode	
	Charge	-	-	✓*18	✓*18	✓*18	✓*18	✓*18	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Charge	
KD-HDR50 KD-AHD59	Play/ Search Mode	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓*21	✓	**2	Play/ Search Mode	KD-HDR50 KD-AHD59
	Head/iPod Mode	-	-	-	-	-	-	-	*13	*13	*13	✓*14	✓*14	✓*14	✓*14	✓*14	✓*14	✓*14	✓*14	✓*14	✓*14	✓*14	✓*14	✓*14	**2	Head/iPod Mode	
	iTunes Tagging	-	-	-	-	-	-	-	-	-	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	iTunes Tagging	
	Charge	-	-	✓*18	✓*18	✓*18	✓*18	✓*18	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Charge	
KD-DV5504 KD-DV5505 KD-DV5506 KD-DV5507 KD-DV5588 KD-ADV6580	Play/ Search Mode	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Play/ Search Mode	KD-DV5504 KD-DV5505 KD-DV5506 KD-DV5507 KD-DV5588 KD-ADV6580
	Head/iPod Mode	-	-	-	-	-	-	-	*13	*13	*13	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Head/iPod Mode	
	Artwork on Video Out	-	-	-	-	-	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Artwork on Video Out	
	Video Browsing on Video Out	-	-	-	-	-	-	-	-	✓*2*5	✓*2*5	-	✓*2*5	✓*2*5	✓*2*5	✓*5*9	✓*2*5	✓*2*5	✓*2*5	✓*2*5	✓*5*9	✓*5*9	✓*2*5	✓*2*5	**2	Video Browsing on Video Out	
	Charge	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Charge	
KD-AVX20*11 KD-AVX40*11 KD-AVX55 KW-AVX72DT KD-AVX77 KW-AVX720 KW-AVX724 KW^AVX725 KW-AVX726 KW-AVX728 KW-ADV792 KW-AVX820 KW-AVX824 KW-AVX825 KW-AVX826	Play/ Search Mode	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓ (with KS-PD100)	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Play/ Search Mode	KD-AVX20*11 KD-AVX40*11 KD-AVX55 KW-AVX72DT KD-AVX77 KW-AVX720 KW-AVX724 KW^AVX725 KW-AVX726 KW-AVX728 KW-ADV792 KW-AVX820 KW-AVX824 KW-AVX825 KW-AVX826
	Head/iPod Mode	-	-	-	-	-	-	-	✓*3*13*16	✓*3*13*16	✓*3*13*16	✓*11	✓*11	✓*11	✓*11	✓*11	✓*11	✓*11	✓*11	✓*11	✓*11	✓*11	✓*11	✓*11	**2	Head/iPod Mode	
	Artwork on Video Out	-	-	-	-	-	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Artwork on Video Out	
	Video Browsing on Video Out	-	-	-	-	-	-	-	-	✓*3*5*17	✓*3*5*17	-	✓*3*5*17	✓*3*5*17	✓*3*5*17	✓*5*10*17	✓*3*5*17	✓*3*5*17	✓*3*5*17	✓*3*5*17	✓*5*10*17	✓*5*10*17	✓*3*5*17	✓*3*5*17	**2	Video Browsing on Video Out	
	Charge	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Charge	
KW-NT1*12	Play/ Search Mode	-	-	-	-	-	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Play/ Search Mode	KW-NT1*12
	Head/iPod Mode	-	-	-	-	-	-	-	*13	*13	*13	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Head/iPod Mode	
	Artwork on Built-in Monitor	-	-	-	-	-	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Artwork on Built-in Monitor	
	Video Browsing on Video Monitor	-	-	-	-	-	-	-	-	✓*5*9*24	✓*5*9*24	-	✓*5*9*24	✓*5*9*24	✓*5*9*24	✓*5*9*19*24	✓*5*9*24	✓*5*9*24	✓*5*9*24	✓*5*9*19*24	✓*5*9*19*24	✓*5*9*19*24	✓*5*9*24	✓*5*9*19*24	**2	Video Browsing on Video Monitor	
	Charge	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Charge	

KD-R610 KD-A615 KD-R618 KD-R616 KD-R611 KW-XR610 KW-XR616 KW-XR611 KW-XR614	Play/ Search Mode	-	-	-	-	-	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓*21	✓	**2	Play/ Search Mode	KD-R610 KD-A615 KD-R618 KD-R616 KD-R611 KW-XR610 KW-XR616 KW-XR611 KW-XR614
	Head/iPod Mode	-	-	-	-	-	-	-	*13	*13	*13	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Head/iPod Mode	
	Charge	-	-	✓*18	✓*18	✓*18	✓*18	✓*18	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Charge	
KD-R710 KD-R716 KD-R711 KD-R717 KD-R810 KD-A815 KD-R816 KD-R811 KW-XR810 KW-XR816 KW-XR811 KW-XR817	Play/ Search Mode	-	-	-	-	-	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓*21	✓	**2	Play/ Search Mode	KD-R710 KD-R716 KD-R711 KD-R717 KD-R810 KD-A815 KD-R816 KD-R811 KW-XR810 KW-XR816 KW-XR811 KW-XR817
	External/ Head/iPod Mode	-	-	-	-	-	-	-	*13	*13	*13	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	External/ Head/iPod Mode	
	Charge	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Charge	
KD-HDR60 KD-AHD69	Play/ Search Mode	-	-	-	-	-	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓*21	✓	**2	Play/ Search Mode	KD-HDR60 KD-AHD69
	Head/iPod Mode	-	-	-	-	-	-	-	*13	*13	*13	✓*14	✓*14	✓*14	✓*14	✓*14	✓*14	✓*14	✓*14	✓*14	✓*14	✓*14	✓*14	✓*14	✓*14	**2	Head/iPod Mode	
	iTunes Tagging	-	-	-	-	-	-	-	-	-	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	iTunes Tagging	
	Charge	-	-	✓	✓	✓*18	✓*18	✓*18	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Charge	
KW-AVX730 KW-ADV793 KW-AVX735 KW-AVX736 KW-AVX830 KW-AVX835 KW-AVX836 KW-AVX838	Play/ Search Mode	-	-	-	-	-	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Play/ Search Mode	KW-AVX730 KW-ADV793 KW-AVX735 KW-AVX736 KW-AVX830 KW-AVX835 KW-AVX836 KW-AVX838
	Head/iPod Mode	-	-	-	-	-	-	-	*13	*13	*13	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Head/iPod Mode	
	Artwork on Video Out and Built-in Monitor	-	-	-	-	-	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Artwork on Video Out and Built-in Monitor	
	Video Browsing on Video Monitor	-	-	-	-	-	-	-	-	✓*3*5*25	✓*3*5*25	-	✓*3*5*25	✓*3*5*25	✓*3*5*25	✓*5*10*25	✓*3*5*25	✓*3*5*25	✓*3*5*25	✓*3*5*25	✓*5*10*25	✓*5*10*25	✓*3*5*25	✓*3*5*25	**2	Video Browsing on Video Monitor	
	Charge	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Charge	
KW-NT3HDT KW-NT3HD KW-NT3	Play/ Search Mode	-	-	-	-	-	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓*21	✓	**2	Play/ Search Mode	KW-NT3HDT KW-NT3HD KW-NT3
	External/ Head/iPod Mode*23	-	-	-	-	-	-	-	*13	*13	*13	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	External/ Head/iPod Mode*23	
	Artwork on Built-in Monitor	-	-	-	-	-	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Artwork on Built-in Monitor	
	Video Browsing on Video Monitor	-	-	-	-	-	-	-	-	✓*5*9*22	✓*5*9*22	-	✓*5*9*22	✓*5*9*22	✓*5*9*22	✓*5*9*22	✓*5*9*22	✓*5*9*22	✓*5*9*22	✓*5*9*22	✓*5*9*22	✓*5*9*22	✓*5*9*22	✓*5*9*22	**2	Video Browsing on Video Monitor	
	iTunes Tagging	-	-	-	-	-	-	-	-	-	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	iTunes Tagging	
	Charge	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	**2	Charge	
		iPod 3rd generation 10GB/15GB/20GB	**iPod 3rd generation 30GB/40GB**	**iPod mini**	**iPod 4th generation 20GB**	**iPod 4th generation 40GB**	**iPod 4th generation(color display) 20GB/30GB**	**iPod 4th generation (color display) 40GB/60GB**	**iPod nano** 1st generation	**iPod 5th generation(video) 30GB**	**iPod 5th generation(video) 60GB/80GB**	**iPod nano** 2nd generation (aluminum)	**iPod classic** (2007)	**iPod nano** 3rd generation(video)	**iPod touch** 1st generation	**iPhone**	**iPod nano** 4th generation(video)	**iPod classic** (2008)	**iPod classic** (2009)	**iPod touch** 2nd generation*20	**iPhone 3G**	**iPhone 3GS**	**iPod nano** 5th generation (video camera) 8GB/16GB	**iPod touch** 3rd generation*20	**iPad, iPad 3G iPad(Wi-Fi), iPad(Wi-Fi + 3G)**		

To identify iPod models, please check Apple Inc. web site.

:Available
-:Not covered under warranty
*1:The iPod adapter has the possibility of hanging up while using iPod nano 2nd generation.

*2:To realizethis function, special cable(KS-U19 or KS-U29) is necessary.

*3:To realizethis function, special cable(KS-U20 or KS-U30) is necessary.

*4:To connect iPod directly, KS-U18 is necessary for KD-PDR41and KD-G647.

*5:At Video Browsing mode, "Movies","TV Shows","Video Podcasts","Music Videos","Video Playlists" is suppoerted. "Rented Movies" is not supported.

*6:Setting of Shuffle mode of iPod becomes Off just after connected with the following models.
KD-DV7400, KD-ADV7490, KD-DV7401/2, KD-DV7404, KD-DV7405/6, KD-DV7407/8,KD-AVX22, KD-AVX44, KD-ADV49, KW-AVX810, KW-AVX815, KW-AVX816, KW-NX7000, KW-NXD707.

*7: While playing back the iPod touch connected, sounds may sometimes jump or be interrupted. It may happen because of the data communication processing on the unit, not a malfunction.

*8:These models do not have the function to charge new iPod. If you want to charge new iPod by these models, please check Apple Inc. web site. > Apple Store > Shop iPod > iPod Accessories > Power > Charging Adapter for iPhone 3G. http://store.apple.com/us/product/TS696LL/A?fnode=MTY1NDA4NA&mco=MjIwMTg2NQ

*9:To realizethis function, special cable KS-U29 is necessary.

*10:To realizethis function, special cable KS-U30 is necessary.

*11: KD-AVX20 and KD-AVX40 do not have Head/iPod Mode function. KD-AVX20 and KD-AVX40 have only Head Mode.

*12: KW-NT1 does not work with KS-PD100.

*13:Head/iPod Mode does not work on iPod 5G and iPod nano 1G via USB Audio.

*14: When Head/iPod mode is switched to iPod mode, iPod turns into the pause mode and does not play back until pushing the play button of iPod itself.

*15: To operate iPod smoothly, please set "iPod Artwork" to "off" on AV Menu - Setup - Disc Setup 1.

*16: To listen to the sound in "iPod Mode", please set "AV Input" to "iPod(Off)" on AV Menu - Setup - Input.

*17: To display the vide in iPod, please set "AV Input" to "iPod(Off)" on AV Menu - Setup - Input.

*18: It takes a time to start charging after connect ing.

*19:Video image may not be displayed on screen when iPod mode.

*20:There is no audio output when connected to OS3.0 iPod/iPhone.

*21:If you hear same noise, please set "Voice Over" function to "OFF" on iPod and iTunes.

*22 :If External/Head/iPod mode is switched during video is playing, iPod stops and play key of the head unit on head mode becomes invalid. To play back iPod, on External/iPod mode, please operate iPod itself. On Head mode, please select the music/video in the list of the head unit.

*23 :In iPod mode, to control iPod from the head unit is disable.

*24 :If Head/iPod mode is switched during video is playing, iPod stops and play key of the head unit on head mode becomes invalid. To play back iPod, on iPod mode, please operate iPod itself. On Head mode, please select the music/video in the list of the head unit.

*25 :To display the video in iPod, please set "AV Input" to "iPod Video" on AV menu -Setup- Input.

**1 :JVC Car Head Units which were designed before 2009 are not made to work with iPhone.

Note: *Not compatible with iPod 1st + 2nd generation and iPod shuffle 1st + 2nd + 3rd generation because they have no dock connector.